



# Connecting to the Internet With a Ethernet DSL modem – Windows 2000

Please follow the installation steps that came with your modem. See the document: [Ethernet DSL Modem Hardware Installation](#).


Your modem is pre-configured with the correct user name and password. You do not need to perform any additional changes.

**NOTE:** Once you have plugged everything in please make sure that the lights on the front of the modem labeled “Power”, “ADSL” and “PC” are solid. The lights should be on and not blinking.

Next, you must verify the settings of your Ethernet card. Follow the steps below. Note that the example is for Windows 2000. The steps may be slightly different for your operating system.


## 1. Open Control Panels

Click the **Start** menu. Select **Settings**, then **Control Panels**.



## 2. Launch Network Control Panel

Double-click the icon labeled **Network and Dial-up Connections**.



## 3. Select Local Area Connection


Click once with the right mouse button on **Local Area Connection** and then click on **Properties**



#### **4. Select TCP/IP Bindings for Ethernet Card**

Select the TCP/IP bindings for your Ethernet card. Please see the documentation that came with your Ethernet card if you need more information.

Once selected, click the **Properties** button.



#### **5. IP Address**

Make sure that the radio button labeled **Obtain an IP address automatically** is selected.

Make sure that the radio button labeled **Obtain DNS server address automatically** is selected.



#### **6. Gateway**

Click on the **Advanced** button.

Make sure that there are no gateways installed. If there are, remove them.



#### **7. DNS**

Select the **DNS** tab.

Make sure that there are no DNS numbers listed in either text boxes. If there are any, please remove it.



#### **8. Launch Browser**

You can check whether your Internet connection is working by launching Internet Explorer or Netscape Navigator. Type in <http://www.pathcom.com> in the address bar and see if the website loads. If not, please contact technical support at (416) 214-6363.